

Installation Guide

TouchPanel Driver MT 7

Important

Please read this Installation Guide carefully to familiarize yourself with safe and effective usage.

Introducing MT 7	2
1. Setting Up	3
1-1. System Requirements.....	3
1-2. Installing MT 7.....	3
1-3. Linking Monitors (For Multiple Monitor Environment Only).....	8
1-4. Calibration	9
1-5. Uninstalling MT 7	12
2. Touch Panel Settings.....	13
2-1. Touch Settings Tab	13
2-2. Edge Adjustment Tab	17
2-3. Tools Tab.....	17
3. Cautions for the Use of the Touch Panel	18
4. Troubleshooting.....	20



Introducing MT 7

MT 7 is the driver software necessary to use EIZO touch panel monitors (EIZO FlexScan L***T-C Series) with Windows 7/Vista/XP.

Copyright © 2008-2013 EIZO Corporation All rights reserved.

No part of this manual may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electric, mechanical, or otherwise, without the prior written permission of EIZO Corporation.

EIZO Corporation is under no obligation to hold any submitted material or information confidential unless prior arrangements are made pursuant to EIZO Corporation's receipt of said information. Although every effort has been made to ensure that this manual provides up-to-date information, please note that this products specifications are subject to change without notice.

Windows, Windows Vista are registered trademarks of Microsoft Corporation.

EIZO and EIZO Logo are registered trademarks of EIZO Corporation in Japan and other countries.

The screen shots used in this manual are taken from 3M products.

1. Setting Up

1-1. System Requirements

MT 7 operates under the system shown below.

OS	<ul style="list-style-type: none"> • Windows 7 (32 bit / 64 bit) • Windows Vista Service Pack 2 (32 bit) • Windows XP Service Pack 3 (32 bit)
Monitor	EIZO FlexScan L***T-C series

1-2. Installing MT 7

Note

- When reinstalling MT 7, restart the PC after uninstalling MT 7, and then install it again.

- 1** Connect the PC and the monitor using the signal cable that matches the type of the connector
- 2** When using the RS-232C cable, connect one end of the cable to the RS-232C port of the monitor and the other end to the COM port of the PC

Note

- Do not use a conversion adapter for connection. The touch panel display may not work properly.
- When using the USB cable for connection, be sure to connect the monitor to the PC after installing MT 7.

- 3** Connect the power cord to the power connector and the power outlet
- 4** Turn on the monitor
- 5** Turn on the PC, and log on to the user account that has the “Administrators” privilege

For user account privilege settings, contact your system administrator.

6 Prepare for installation

■ To install the software from the “EIZO Touch Panel Disk” CD-ROM

After inserting the “EIZO Touch Panel Disk” CD-ROM into the CD-ROM drive the menu will open automatically.

Click [Touch Panel Driver Windows 7/Vista/XP (32 bit)] or [Touch Panel Driver Windows 7 (64 bit)] in the “Drivers” tab.

Click the [Install] button to start the setup wizard.

Tips


- If the menu does not open automatically, double-click “Launcher.exe” from the drive into which the “EIZO Touch Panel Disk” CD-ROM has been inserted. The menu starts up.

■ To download and install the software from our website

After extracting the downloaded file, double-click “Setup.exe” in the “MT 7” folder to start the setup wizard.

Tips


- The “User Account Control” dialog may appear. *
Click [Yes]/[Allow] to open the menu.



* The “User Account Control” dialog does not appear depending on the setting.

7 Start the setup wizard

Click [Next >].



8 Confirm the software license agreement


Read the software license agreement carefully. Select “Accept--Installation will continue.” and click [Next >] if you wish to use MT 7.



9 Specify the location to install the software


To change the folder, click [Browse...], and specify the folder in which you want to install the software.

After specifying the folder, click [Next >].



10 Select the setup type


Select “Typical” and click [Next >].



11 Select the driver type

Select an appropriate type, depending on the OS and monitor configuration, and click [Next >].

OS	Monitor Configuration	Driver Type
Windows 7	Single monitor configuration	“Touch digitizer uses Windows' built-in touch functionality”
	Multiple monitor configuration	“Legacy mouse uses older MicroTouch driver technology”
Windows Vista/XP	Single monitor configuration/ Multiple monitor configuration	“Legacy mouse uses older MicroTouch driver technology”




Tips

- Under Windows 7, the types of touch operations depend on your monitor configuration (type of installed driver). For information on the types of touch operations, see [page 19](#).


12 Confirm the current settings

Click [Next >] to start the installation.



13 Finish the installation

Click [Finish].



The “Control Panel” icon appears on your desktop.



14 When using the USB cable to connect the monitor to the PC, connect the USB cable to the USB port (upstream) of the monitor and the USB port (downstream) of the PC after installing MT 7


15 Restart the PC

1-3. Linking Monitors (For Multiple Monitor Configuration Only)

To use the touch panel in multiple monitor configuration, follow the procedure below to link the touch panel and monitors. The procedure is unnecessary when using only one monitor. Please skip to 1-4.

1 Click [Start]-[All Programs]-[MicroTouch MT 7]-[MultiMonitor Manager]

“MT 7 Multiple Monitor Manager” window opens. The monitors are displayed with colored frames.



2 Click with the mouse

The icon and colored frame blink.

3 Touch the screen to link to with a finger

The icon in “Touch Screens” (in the above image,  or ) blinks.

4 Refer to Steps 2 and 3 to link remaining monitors

5 Click [Save & Exit] to finish

Tips

- When using the touch panel in multiple monitor configuration, please see [“Using Touch Panel in Multiple Monitor Environment”](#) on page 18.

1-4. Calibration

After completing the installation of driver, please make sure to perform the following procedure to calibrate the screen.

The calibration method depends on the type of OS being used (and the monitor configuration).


- Single monitor configuration under Windows 7 [page 9](#)
- Multiple monitor configuration under Windows 7 [page 10](#)
- Windows Vista or Windows XP [page 10](#)

NOTE

- Do not put your hands or any metal close to the screen because the screen is susceptible to the dielectric object.

Single monitor configuration under Windows 7

- 1** Click [Start]-[Control Panel]-[Hardware and Sound]-[Tablet PC Settings]
“Tablet PC Settings” window opens.




- 2** Click [Calibrate...] in the “Display” tab

The calibration window with a white background opens.

- 3** Touch the calibration target for a few seconds with a finger, then release

The calibration target appears on the screen 16 times, starting from the top left to top right and then down to the bottom left to bottom right.



Tips

- For the second or subsequent calibration, the calibration target appears four times.

4 Click [Yes]

5 Click [OK] to close the window


Multiple monitor configuration under Windows 7

Windows Vista or Windows XP

1 Click [Start]-[All Programs]-[MicroTouch MT 7]-[Control Panel]

Tips

- The Control Panel window can also be opened from the “Control Panel” icon on your desktop. “MT 7 Software Control Panel” window opens.




2 Click [Calibrate] in the “Main” tab

The calibration window with a white background opens.

3 Touch the calibration target for a few seconds with a finger, then release

The calibration target appears on the screen in three locations, the bottom left, top right and top left, in this order.



NOTE

- When the screen is not touched for twenty seconds, the calibration target will be hidden. When the following messages are displayed, do not touch the screen and wait until the messages disappear.

- “Calibration timed out. Please do not touch the screen.”
- “Restoring data. Please do not touch the screen.”

After the messages disappear, perform the calibration again from the Step 2.

4 Click [Accept]

5 When using the touch panel in multiple monitor configuration, from the pull-down list of “Controller ID” in the “Main” tab, select an ID different from the one currently shown and then repeat Steps 2 to Step 4

6 Click [Close] to close the window

1-5. Uninstalling MT 7

Note


- Cautions for uninstallation
 - Before uninstalling MT 7, be sure to exit all touch panel setting windows such as the calibration window and the MT 7 Control Panel.
-

1 Log on to the user account that has the “Administrators” privilege

2 Click [Start]-[All Programs]-[MicroTouch MT 7]-[Uninstall MT 7]


Tips

- The “User Account Control” dialog may appear. *
Click [Y]es/[A]llow to open the menu.



* The “User Account Control” dialog does not appear depending on the setting.

3 Click [Y]es on the “Confirm File Deletion” window



4 Restart the PC

2. Touch Panel Settings

Use the MT7 Control Panel to configure the touch panel.

Note

- For single monitor configuration under Windows 7, a different Windows 7 control panel is used to configure some settings.

Click [Start]-[All Programs]-[MicroTouch MT 7]-[Control Panel] to open the Control Panel.

Tips

- The Control Panel can also be opened from the “Control Panel” icon on your desktop.


This section describes about the items that can be set in each tab of the Control Panel.

2-1. Touch Settings Tab

Enables you to change the settings of the screen response to your touch operation.

Tips

- Any changed settings will be applied as they are changed.



Changing Touch Modes [Touch Modes]

Touch Modes include three modes. Change the mode as needed.

Note

- For single monitor configuration under Windows 7, do not change the setting (that is, use the initial value of “Drawing”).

Mode Name	Touch Control and Application
Drawing (Default Setting)	Suitable for drawing, painting, illustrating and other graphic applications. Click: Touch the screen with a finger. Double-click: Quickly touch the same spot twice on the screen with a finger. Drag: Touch and slide on the screen with a finger.
Touchdown	Suitable for applications such as a calculator, which is button-based operation. Click: The action is recognized by touching the screen. *Drawing and dragging are not supported.
Liftoff	Suitable for applications that require very precise clicking. Click: The action is recognized by lifting a finger off the screen. *Drawing and dragging are not supported.

The selected button turns green and the mode is applied.

Setting Right-Click Simulated Function

This setting allows a right mouse click to be simulated.

The setting depends on the type of OS being used (and the monitor configuration).

- Single monitor configuration under Windows 7 [page 15](#)
- Multiple monitor configuration under Windows 7 [page 15](#)
- Windows Vista or Windows XP [page 15](#)

Tips

- For information on the right-click operation, see [page 19](#).

Single monitor configuration under Windows 7

1 Click [Start]-[Control Panel]-[Hardware and Sound]-[Pen and Touch]

“Pen and Touch” window opens.

2 Click [Use your finger as an input device] in the “Touch” tab

3 Select [Press and hold] under [Touch actions] and click [Settings...]

“Press and Hold Settings” window opens.

4 Select [Enable press and hold for right-clicking] and click [OK]

Tips


- Select and change [Right-click mode activation] and/or [Press and hold duration] as appropriate.

5 Click [OK] to close the window

Multiple monitor configuration under Windows 7 Windows Vista or Windows XP [Right-click Tool]

1 Click [Right-click]

The icon below appears on your desktop.



Setting Touch Sound [Touch Sound]

Enables you to specify the following three different touch sound settings:

The setting changes in turn ([No beep] - [Liftoff] - [Touchdown]) each time the button is clicked.


Name	Setting Detail
No beep (Default Setting)	No beep is sounded by a touch.
Liftoff	A beep is sounded when your finger leaves the screen.
Touchdown	A beep is sounded when your finger touches the screen.

NOTE

- Under Windows 7, touch sound is only output through the audio output terminal of the PC. To hear touch sound, connect speakers.

Setting Double-click [Double-click]

Enables you to set the speed and area of double-click operation.



Setting the Speed of Double-click

Move the upper slide bar left or right.

The speed is faster when moved to the right and slower when moved to the left.

Setting the Area where the Double-click Operation is Recognized

Move the lower slide bar left or right.

The area is larger when moved to the right and smaller when moved to the left.

Tips


- To check the set speed and area, double-click (quickly touch twice) the glove on the lower right side. When the touch operation is recognized, the glove will start spinning. When it is double-clicked again, it will stop spinning.

NOTE

- The change of the setting will affect the double-click setting of your mouse.

2-2. Edge Adjustment Tab

When it is difficult to click small items such as a check button or radio button on the edge of the screen, change the setting. The cursor location is moved further to the edge of the screen in the specified area than the actual touched location.



1 Specify the area for edge adjustment by moving the slide bar

The marks on the slide bar indicate the distance from the edge of the screen as a percentage. In the specified area, the cursor location is moved further to the edge of the screen and the items on the edges of screen can be touched more easily.

Tips

- To check the adjustment result, click [Test]. The specified area is shown in a different color. To end the check, click [End Test].

2-3. Tools Tab

Enables you to confirm the version information and perform operation checks, as well as more advanced settings.

NOTE

- Do not change the settings in this tab unless you are familiar with the settings of the touch panel.

3. Cautions for the Use of the Touch Panel

While starting the PC and monitor

- Do not touch the touch panel.
It may cause the incorrect cursor position or disable the touch operation.

Powersaving function for the PC

- When the PC is in system standby status, the PC cannot be resumed by touching the touch panel.
Operate the mouse or the keyboard to resume the PC from system standby.


During calibration

- Do not put your hands or any metal close to the screen because the screen is susceptible to the dielectric object.


Using Touch Panel in Multiple Monitor Configuration

- In the default settings, the secondary monitor conforms to the settings of the primary monitor, but once settings different from those of the primary monitor are set on the secondary monitor, it no longer conforms to the primary monitor's settings.
- When the resolution of the monitor is changed, the touch operation and calibration may not work correctly. In this case, reinstall MT 7.
- After installing MT 7 in multiple monitor configuration, if the graphics board settings are changed to either Ex. 1 or 2, MT 7 must be reinstalled.

Ex. 1






Ex. 2



Touch Operations

- The types of touch operations available depend on the type of OS being used (and the monitor configuration).

OS	Windows 7 (in single monitor configuration)	Windows 7 (in multiple monitor configuration) Windows Vista Windows XP
Operation • Click (Tap)	Touch and release the screen once with your finger.	
• Double-click (Double-tap)	Touch and release the screen twice in quick succession with your finger.	
• Drag	Touch the screen and move your finger without releasing the screen.	
• Right-click	1.Touch and keep touching the screen without moving your finger on it. A circle is drawn around the touch position. 2.When the circle is complete, release your finger. 	1.Touch an icon like this that appears on the screen.  The mouse icon's right button turns blue. 2.Touch and release the screen. * This type of operation works only once. After it works once, a screen touch is reset to simulate an ordinary left-click operation.
• Scroll	Touch a scrollable screen and slide your finger vertically without releasing the screen. 	-
• Flick	Touch the screen and flick your finger on the screen. 	-

NOTE

- For single monitor configuration under Windows 7, the Windows Touch function is supported. However, a multi-touch operation using two fingers is not supported.

4. Troubleshooting

If a problem still remains after applying the suggested remedies, contact your local dealer.

Problems	Possible cause and remedy
1. Touch operation is disabled.	<ul style="list-style-type: none"> Check that the monitor and PC are connected via a USB cable. (If the OS being used is Windows 7) If the monitor configuration (single or multi) differs from that when the driver was installed, touch operations may not work or may work differently (from those shown on page 19). If the monitor configuration has been changed after installing the driver, an appropriate driver needs to be reinstalled.
2. The cursor does not appear on the touched position. They become point symmetric with respect to the center of the screen.	<ul style="list-style-type: none"> Calibrate the screen again.
3. The cursor does not appear on the touched position, or does not operate properly.	<ul style="list-style-type: none"> Connect the monitor to the PC with the cable indicated in the Setup Manual or User's Manual of the monitor. Using a conversion adapter, the touch panel may not operate properly. If the touch panel is dirty, the touch panel may not operate properly. Refer to the User's Manual of the monitor to clean the touch panel. Do not touch the touch panel while the PC or monitor is starting. It may cause the incorrect cursor position or disable the touch operation. Leave the touch panel untouched for approximately two minutes, or turn on and off the monitor. If the problem persists, calibrate the screen again. (If the OS being used is Windows 7 (in multiple monitor configuration), Windows Vista, or Windows XP) If "Touch Modes" is set to "Drawing" in the "Touch Settings" tab of the "Control Panel", select a setting other than "Drawing."
4. Cursor is jittery.	<ul style="list-style-type: none"> When multiple monitors are placed close to each other, leave space between monitors.
5. "CBL" appears in "Touch Screen Status" - "Support Information" in the "Main" tab of the "Control Panel".	<ul style="list-style-type: none"> This may appear when using the USB cable to connect the monitor to the PC, but does not affect the operation.
6. No touch sound.	<ul style="list-style-type: none"> The touch sound may not be output from the audio output terminal of the PC depending on the hardware configuration. (If the OS being used is Windows 7) Sound is only output through the audio output terminal of the PC.
7. (If the OS being used is Windows 7 (in multiple monitor configuration), Windows Vista, or Windows XP) The following icon does not appear on your desktop by clicking [Right-click Tool] button. 	<ul style="list-style-type: none"> When the PC are not restarted after installing the driver, the icon (see the left column) does not appear on your desktop by clicking the [Right-click Tool] button in the "Touch Settings" tab of the "Control Panel". Restart the PC.
8. (If the OS being used is Windows 7 (in single monitor configuration)) Calibration does not work correctly.	<ul style="list-style-type: none"> Reset the touch panel to a state before calibration (by clicking [Reset] in the "Screen" tab of the "Tablet PC Settings" control panel) and then calibrate the touch panel again.
9. (When using in multiple monitor situation) Touch operation and calibration do not work correctly.	<ul style="list-style-type: none"> When the resolution of the monitor is changed, the touch operation and calibration may not work correctly. In this case, reinstall MT 7.



EIZO Corporation

<http://www.eizo.com>

4th Edition-April, 2013

03V22563D1
(U.M-MT7)