

## Compatibility between FlexScan EV2780 and Devices Equipped with USB Type-C

[ Items of validation ]

- Display BIOS image correctly
- Display the image correctly with the recognized resolution
- Plug & Play works correctly
- Display correct color
- There is no noise and blinking
- "Standby", "Sleep" and "Shut down" functions work correctly
- USB works correctly
- **Power Delivery works correctly when the device is working and sleeping.**

This information is provided based on our in-house testing. We do not guarantee the compatibility in respective user environments as the manufacture of the graphics board may differ.

Added information

Device information						Compatibility information (USB Type-C)		
Type	Vendor	Product name	OS	Graphics device	Graphics driver	Compatibility	Power Delivery	Note
Laptop	Apple	MacBook Early 2015	macOS Sierra 10.12.1 Beta	Intel HD Graphics 5300	-	Yes	Yes	
Laptop	Apple	MacBook Early 2016	macOS Sierra 10.12.1 Beta	Intel HD Graphics 515	-	Yes	Yes	
Laptop	Apple	MacBook Pro (Late 2016) 13"	macOS Sierra 10.12.1	Intel Iris Graphics 540	-	Yes	Yes (only 30W)	* It is possible that battery charging is not available. Please use the supplied AC adapter in that case.
Laptop	Apple	MacBook Pro (Late 2016) 13" with Touch Bar	macOS Sierra 10.12.1	Intel Iris Graphics 550	-	Yes	Yes (only 30W)	
Laptop	Apple	MacBook Pro (Late 2016) 15" with Touch Bar	macOS Sierra 10.12.1	Radeon Pro 455 Intel HD Graphics 530	-	Yes	Yes (only 30W)	* In Sleep Mode, battery charging is available with 15W setting. (It may take about 8 hours.)
Laptop	DELL	XPS12 9250	Windows 10 64-bit	Intel HD Graphics 515	20.19.15.4454	Yes	Yes (only 30W)	Enable Compatibility Mode of EV2780.
Laptop	DELL	XPS13 9350	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4454	Yes	Yes (only 30W)	Images are sometimes not displayed. Detach and re-attach the USB cable.
Laptop	DELL	XPS15 9550	Windows 10 64-bit	Intel HD Graphics 530	20.19.15.4454	Yes	No	USB functions sometimes do not work. Detach and re-attach the USB cable.
Laptop	HP	Elite X2 1012 G1	Windows 10 64-bit	Intel HD Graphics 515	20.19.15.4457	Yes	Yes (only 30W)	
Laptop	HP	EliteBook Folio G1	Windows 10 64-bit	Intel HD Graphics 515	20.19.15.4377	Yes	Yes (only 30W)	
Laptop	VAIO	VAIO S11	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4463	Yes	Not supported	
Laptop	HP	Zbook Studio G3	Windows 7 Professional	Intel HD Graphics P530 NVIDIA Quadro M1000M	20.19.15.4444 10.18.13.5449	Yes	Not supported	Run Windows Update before connecting EV2780.
Laptop	HP	Zbook Studio G4	Windows10 Pro Build 1607	Intel HD Graphics 630 NVIDIA Quadro M1200	21.20.16.4574 21.21.13.7743	Yes	Not supported	USB functions do not work. Name of monitor is not recognized on OS.
Laptop	DELL	New Alienware 17 R3	Windows 10 64-bit	Intel HD Graphics 530 NVIDIA GeForce GTX970M	10.18.15.4281 10.18.13.5354	Yes	Not supported	
Laptop	HP	Spectre x2	Windows 10 64-bit	Intel HD Graphics 515	20.19.15.4364	No	Not supported	Images are not shown correctly.
Laptop	HP	Zbook 15 G3	Windows 7 Pro 64-bit	Intel HD Graphics 530 NVIDIA Quadro M1000M	20.19.15.4331 10.18.13.5461	Yes	Not supported	
Laptop	HP	Zbook 15 G4	Windows10 Pro Build 1607	Intel HD Graphics 630 Radeon Pro WX4150 Graphics	21.20.16.4574 21.19.170.512	Yes	Not supported	USB functions do not work. Name of monitor is not recognized on OS.
Laptop	HP	Zbook 17 G4	Windows10 Pro Build 1607	Intel HD Graphics 630 NVIDIA Quadro P4000	21.20.16.4574 21.21.13.7743	Yes	Not supported	It is possible that BIOS is not displayed. Name of monitor is not recognized on OS. Enable Compatibility Mode of EV2780.
Laptop	Lenovo	IdeaPad YOGA 900	Windows 10	Intel HDGraphics 520	20.19.15.4326	No	Not supported	Images are not shown correctly.
Laptop	Acer	Switch Alpha 12	Windows 10 64-bit	Intel HDGraphics 530	20.19.15.4454	Yes	Yes (only 30W)	
Laptop	ASUS	ROG G752VT-DH72	Windows 10 64-bit	NVIDIA GeForce GTX970M	10.18.13.5923	Yes	Not supported	
Laptop	MSI	GS40 6QD PHANTOM	Windows 10 64-bit	Intel HD Graphics 530 NVIDIA Geforce GTX960M	20.19.15.4416 10.18.13.6212	Yes	Not supported	
Laptop	MSI	GT72 6QD DOMINATOR G	Windows 10 64-bit	NVIDIA Geforce GTX970M	10.18.13.6881	No	Not supported	Resolution should be changed to 1280x800.
Laptop	Razer	Blade Stealth - 4K	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4331	Yes	No	
Laptop	Google	Chromebook Pixel 2015	ChromeOS 64bit 53.0.2785.144	unconfirmed	-	Yes	Yes	
Motherboard	Gigabyte	GA-Z170X-UD5 TH	Windows 10 64-bit	Intel HD Graphics 530	20.19.15.4364	Yes	Not supported	Enable Compatibility Mode of EV2780.
Motherboard	Gigabyte	GA-Z170X-Gaming 7	Windows 10 64-bit	Intel HD Graphics 530	20.19.15.4474	Yes	Not supported	Enable Compatibility Mode of EV2780.
Smartphone	Microsoft	Lumia 950/950XL	Windows 10 Mobile	unconfirmed	-	No	Yes	System freezes.
Smartphone	LG	G5 H860N	Android 6.0.1	unconfirmed	-	No	Yes	System freezes.
Smartphone	HTC	HTC 10 M10h	Android 6.0.1	unconfirmed	-	Yes	Yes	Audio and USB functions do not work.

Firmware update is required with the EV2780 to connect to MacBook Pro (Late 2016) and use it at 30W setting. See below for the details.

[www.eizo.com/global/support/compatibility/pc/mac/thunderbolt3-ev2780/](http://www.eizo.com/global/support/compatibility/pc/mac/thunderbolt3-ev2780/)