

## Compatibility between FlexScan EV2785 and Devices Equipped with USB Type-C

[ Items of validation ]

- Displays BIOS image correctly
- Displays correctly the image with the recognized resolution
- Plug & Play works correctly
- Displays correct color
- There is no noise and blinking
- "Standby", "Sleep" and "Shut down" work correctly
- USB works correctly
- Power Delivery works correctly.

This information is provided based on our in-house testing. We do not guarantee compatibility in respective user environments.

Device information						Compatibility information (USB Type-C)		
Type	Vendor	Product name	OS	Graphics device	Graphics driver	Compatibility	Power Delivery	Note
Laptop	Apple	MacBook Early 2016	macOS Sierra 10.12.5	Intel HD Graphics 515	-	Yes	Yes	
	Apple	MacBook Pro 15inch Late 2016	macOS Sierra 10.12.5	Intel HD Graphics 530 / Radeon Pro 455	- / 01.00.98	Yes	Yes	
	Apple	MacBook Pro 13inch 2017 with TouchBar	macOS Sierra 10.12.5	-	-	Yes	Yes	
	Apple	MacBook Pro 15inch 2017 with TouchBar	macOS Sierra 10.12.5	-	-	Yes	Yes	
	Panasonic	Let's note CF-XZ6	Windows 10 64-bit	Intel HD Graphics 620	21.20.16.4550	Limited	Not supported	There are some cases where the monitor is not recognized.
	DELL	XPS13 9350	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4454	Yes	Yes	When it doesn't wake up from sleep mode, check the BIOS (UEFI) setting.
	VAIO	VAIO S11	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4463	Yes	Not supported	When it doesn't wake up from sleep mode, push the PC's power button.
	HP	EliteBook Folio G1	Windows 10 64-bit	Intel HD Graphics 515	20.19.15.4483	Limited	Yes	There are some cases where the PC freezes.
	HP	Spectre x360 Conve 13-w010tu	Windows 10 64-bit	IntelR HD Graphics 620	21.20.16.4664	Yes	Yes	
	ASUS	ROG G752VT-DH72	Windows 10 64-bit	NVIDIA GeForce GTX 970M	384.94	Yes	Not supported	
	Lenovo	Yoga 900	Windows 10 64-bit	Intel HD Graphics 520	20.19.15.4463	Yes	Not supported	
	Acer	SF713-51-M707	Windows 10 64-bit	IntelR HD Graphics 615	21.20.16.4534	Yes	Yes	
Desktop	Intel	NUC6I7KYK	-	IntelR Iris Pro Graphics 580	22.20.16.4771	Yes	-	
	MSI	Vortex G65	Windows 10 64-bit	NVIDIA GeForce GTX 960	361.75	Yes	-	
Tablet	Acer	Switch Alpha SA5-271P-574Y	Windows 10 Pro	Intel HD Graphics 520	20.19.15.4454	Yes	Yes	
Smart phone	HTC	HTC 10 M10h	Android 7.0	-	-	Yes	Yes	It can display the image with 1920x1080@60Hz because of 6h4 specifications of this smart phone.
	Samsung	Galaxy S8	Android 7.0	-	-	Yes	Yes	
	LG	V20 (LG-H990)	Android 7.0	-	-	No	Yes	There are some cases where the system freezes.