

This page contains the compatibility information of the FlexScan monitors with USB Type-C capable PCs.

Click to see daisy chain compatibility information for these monitors.

- ▶ [EV2795](#)
- ▶ [EV2495 / EV2490](#)

[Validated Items]

- Displays BIOS image correctly
- Displays the image correctly with the recommended resolution and refresh rate
- Plug & Play works correctly
- Colors display correctly
- No noise and blinking of image
- "Standby", "Sleep", "Restart" and "Shut down" functions work correctly
- USB Type-C function works correctly

[Validated Cables and Peripherals]

USB Type-C cable: CC200SS-5A / CC150SS81G-5A (supplied with monitor), CC100 (sold separately)

Caution: This information is provided based on our in-house testing and we do not guarantee the compatibility in respective user environments.

Laptop PC

Year	Manufacturer	Product	GPU	OS	USB Type-C Function							
					Video, Power Delivery, LAN, USB Hub				Video, Power Delivery, USB Hub			
					EV4340X EV3450XC	EV3240X EV2740X	EV3895	EV2795 EV2495 EV2490	EV2720S EV2740S	FLT	EV2485 EV2480	EV2781
2025	Microsoft	Surface Laptop (7th Edition)	Intel Iris Arc Graphics	Windows 11 (24H2)	Yes	Yes	Yes	Yes *12	Yes	Yes	Yes	Not evaluated
2025	Panasonic	Let's note CF-SC6	Intel Iris Arc Graphics	Windows 11 (24H2)	Yes	Yes	Yes	Yes	Yes	Not evaluated	Yes	Yes
2024	Apple	MacBook Pro (M4)	-	macOS Sequoia (15)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated
2024	Lenovo	ThinkPad T14s Gen 6	AMD Radeon 880M	Windows 11 (24H2)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes (EV2720S is not evaluated)	Not evaluated	Not evaluated	Not evaluated
2024	Panasonic	Let's note CF-FV5	Intel Iris Arc Graphics	Windows 11 (22H2)	Yes	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2023	Apple	MacBook Pro (M3)	-	macOS Sequoia (15)	Yes (EV4340X is not evaluated)	Not evaluated	Not evaluated	Not evaluated	Yes (EV2740S is not evaluated)	Yes	Not evaluated	Not evaluated
2023	Apple	MacBook Pro (M3)	-	macOS Sonoma (14)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated
2023	Apple	MacBook Pro (M3 Pro)	-	macOS Sequoia (15)	Yes	Not evaluated	Not evaluated	Not evaluated	Yes (EV2720S is not evaluated)	Not evaluated	Not evaluated	Not evaluated
2023	Dell	Precision 7780	NVIDIA RTX 5000 Ada	Windows 10 (22H2)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated
2023	Dell	Precision 5680	NVIDIA RTX 3500 Ada	Windows 11 (22H2)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated
2023	Panasonic	Let's note CF-FV4	Intel Iris Xe Graphics	Windows 11 (22H2)	Not evaluated	Yes	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Yes
2023	Panasonic	Let's note CF-QR4	Intel Iris Xe Graphics	Windows 11 (22H2)	Yes	Yes	Yes	Yes	Yes	Not evaluated	Yes	Yes
2023	Panasonic	Let's note CF-SR4	Intel Iris Xe Graphics	Windows 11 (22H2)	Yes	Yes	Yes	Yes	Yes	Not evaluated	Yes	Yes
2022	Apple	MacBook Air (M2)	-	macOS Ventura (13.0.1)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2022	Apple	MacBook Air (M2)	-	macOS Monterey (12.6.1)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	Apple	MacBook Pro 13" (M2)	-	macOS Ventura (13.0.1)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated

Laptop PC

Year	Manufacturer	Product	GPU	OS	USB Type-C Function							
					Video, Power Delivery, LAN, USB Hub				Video, Power Delivery, USB Hub			
					EV4340X EV3450XC	EV3240X EV2740X	EV3895	EV2795 EV2495 EV2490	EV2720S EV2740S	FLT	EV2485 EV2480	EV2781
2022	Dynabook	G83/KV	Intel Iris Xe Graphics	Windows 10 Pro (22H2)	Not evaluated	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	Fujitsu	LIFEBOOK U7312/J	Intel UHD Graphics	Windows 11 (21H2)	Not evaluated	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	Fujitsu	LIFEBOOK U7312/J + FMV-NPR49	Intel UHD Graphics	Windows 11 (21H2)	Not evaluated	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	HP	Elite Dragonfly G3	Intel Iris Xe Graphics☒	Windows 10 (22H2)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes (EV2740S is not evaluated)	Yes	Not evaluated	Not evaluated
2022	Microsoft	Surface Laptop 5	Intel Iris Xe Graphics	Windows 11 (22H2)	Not evaluated	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	Microsoft	Surface Laptop 5 + Surface Thunderbolt 4 Dock	Intel Iris Xe Graphics	Windows 11 (22H2)	Not evaluated	Yes	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2022	Panasonic	Let's note CF-FV1	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Not evaluated
2022	Panasonic	Let's note CF-FV3	Intel Iris Xe Graphics	Windows 11 (21H2)	Not evaluated	Yes	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Yes
2022	Panasonic	Let's note CF-QV1	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Yes
2022	Panasonic	Let's note CF-SV2	Intel Iris Xe Graphics	Windows 11 (21H2)	Not evaluated	Yes	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Yes
2021	Apple	MacBook Pro 14" (M1 Max)	-	macOS Sonoma (14)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2021	Apple	MacBook Pro 14" (M1 Max)	-	macOS Ventura (13)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2021	Apple	MacBook Pro 14" (M1 Max)	-	macOS Monterey (12.6.1)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2021	Dell	Inspiron 7300	Intel Iris Xe Graphics	Windows 10 Pro (22H2)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2021	Lenovo	ThinkPad X1 Nano Gen1	Intel Iris Xe Graphics	Windows 10 Pro (22H2)	Yes (EV4340X is not evaluated)	Not evaluated	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated
2021	Microsoft	Surface Laptop 4	AMD Radion Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2021	Microsoft	Surface Laptop 4 + Surface Dock 2	AMD Radion Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes *7	Not evaluated	Not evaluated	Yes	Yes
2021	Microsoft	Surface Laptop 4	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2021	Microsoft	Surface Laptop 4 + Surface Dock 2	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Yes	Yes *7	Not evaluated	Not evaluated	Yes	Yes
2021	Microsoft	Surface Pro 7+	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated
2021	Microsoft	Surface Pro 7+ + Surface Dock 2	Intel Iris Xe Graphics	Windows 10 Pro (20H2)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated
2021	Panasonic	Let's note CF-QV9	Intel UHD Graphics	Windows 10 Pro	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2021	Panasonic	Let's note CF-SV1	Intel Iris Xe Graphics	Windows 10 Pro (2004)	Not evaluated	Not evaluated	Yes	Yes *10	Not evaluated	Not evaluated	Yes *10	Not evaluated
2020	Apple	MacBook Pro 13" (M1)	-	macOS Big Sur (11.2.3)	Not evaluated	Not evaluated	Conditions apply > Details	Conditions apply > Details	Not evaluated	Not evaluated	Conditions apply > Details	Not evaluated
2020	Dell	Inspiron 13 7300	Intel Iris Xe Graphics	Windows 11 (21H2)	Not evaluated	○	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2020	Lenovo	ThinkPad L13	Intel UHD Graphics 620	Windows 10 Pro	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes *11
2020	Microsoft	Surface Laptop Go	Intel UHD Graphics	Windows 10 Pro (2004)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Ye	Not evaluated
2020	Microsoft	Surface Laptop Go + Surface Dock 2	Intel UHD Graphics	Windows 10 Pro (2004)	Not evaluated	Not evaluated	Yes	Yes *7	Not evaluated	Not evaluated	Yes	Not evaluated
2020	Microsoft	Surface Book 3	Intel Iris Plus Graphics	Windows 10 Pro (1909)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Not evaluated
2020	Microsoft	Surface Book 3 + Surface Dock 2	Intel Iris Plus Graphics	Windows 10 Pro (1909)	Not evaluated	Not evaluated	Yes	Yes *7	Not evaluated	Not evaluated	Yes	Not evaluated
2020	Panasonic	Let's note CF-SV9	Intel UHD Graphics	Windows 10 Pro	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated

Laptop PC												
Year	Manufacturer	Product	GPU	OS	USB Type-C Function							
					Video, Power Delivery, LAN, USB Hub				Video, Power Delivery, USB Hub			
					EV4340X EV3450XC	EV3240X EV2740X	EV3895	EV2795 EV2495 EV2490	EV2720S EV2740S	FLT	EV2485 EV2480	EV2781
2019	Apple	MacBook Pro 16"	Intel UHD Graphics 630	macOS Catalina (10.15.4)	Not evaluated	Not evaluated	Yes *5	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated
2019	ASUS	Chromebook Flip C434TA	Intel UHD Graphics 615	Chrome OS (76.0.3809.136)	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2019	Dell	XPS 13 2-in-1 (7390)	Intel Iris Plus Graphics	Windows 10 Pro (1903)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2019	Dell	G3 15 (3590)	NVIDIA GeForce GTX 1650, Intel UHD Graphics 630	Windows 10 Home	Not evaluated	Not evaluated	Not evaluated	Yes *2	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2019	Lenovo	ThinkPad X390 Yoga	Intel UHD Graphics 620	Windows 10 Home	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2019	Microsoft	Surface Laptop 3	Intel Iris Plus Graphics	Windows 10 Enterprise (1903)	Not evaluated	Not evaluated	Yes *4	Yes *4	Not evaluated	Not evaluated	Yes	Not evaluated
2019	Microsoft	Surface Laptop 3 + Surface Dock 2	Intel Iris Plus Graphics	Windows 10 Enterprise (1903)	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes *8	Not evaluated
2019	Microsoft	Surface Pro 7	Intel Iris Plus Graphics	Windows 10 Enterprise (1903)	Not evaluated	Not evaluated	Not evaluated	Yes *4	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Apple	MacBook Pro 15"	AMD Radeon Pro 555X, Intel HD Graphics 630	macOS Mojave (10.14.6)	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Dell	Inspiron 13 7000 2-in-1 (7375)	AMD Radeon RX Vega 10 Graphics	Windows 10 Home	Not evaluated	Not evaluated	Not evaluated	Yes *10	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Fujitsu	LIFEBOOK WU2/C3	Intel UHD Graphics 620	Windows 10 Home	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Lenovo	Thinkpad T480	Intel HD Graphics 620	Windows 10 Pro (1809)	Not evaluated	Not evaluated	Not evaluated	Yes *6	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Microsoft	Surface Go	Intel HD Graphics 615	Windows 10 Enterprise (1903)	Not evaluated	Not evaluated	Not evaluated	Yes *3	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2015	Dell	XPS 15 (9550)	Intel HD Graphics 530	Windows 10 Pro (1809)	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated

Year	Manufacturer	Product	GPU	OS	USB Type-C Function							
					Video, Power Delivery, LAN, USB Hub				Video, Power Delivery, USB Hub			
					EV4340X EV3450XC	EV3240X EV2740X	EV3895	EV2795 EV2495 EV2490	EV2720S EV2740S	FLT	EV2485 EV2480	EV2781
2024	Apple	Mac Mini (M4)	-	macOS Sequoia (15.2)	Yes	Yes	Yes	Yes	Not evaluated	Yes	Yes	Yes
2024	Apple	Mac mini (M4 Pro)	-	macOS Sequoia (15)	Yes	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated
2023	Apple	Mac Mini (M2)	-	macOS Ventura (13.2.1)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2023	Apple	Mac Mini (M2 Pro)	-	macOS Ventura (13.2.1)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes	Yes
2023	Apple	Mac Studio (M2 Max)	-	macOS Sonoma (14)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated
2023	Apple	Mac Studio (M2 Max)	-	macOS Ventura (13)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2020	Apple	Mac mini (M1)	-	macOS Big Sur (11.3.1)	Not evaluated	Not evaluated	Conditions apply ≥ Details	Conditions apply ≥ Details	Not evaluated	Not evaluated	Conditions apply ≥ Details	Yes
2019	Apple	iMac 27" Retina 5K	AMD Radeon Pro 570X	macOS Mojave (10.14.4)	Not evaluated	Not evaluated	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Apple	Mac mini	Intel UHD Graphics 630	macOS Sonoma (14)	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Apple	Mac mini	Intel UHD Graphics 630	macOS Monterey (13)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Apple	Mac mini	Intel UHD Graphics 630	macOS Monterey (12.6.1)	Not evaluated	Yes	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated	Not evaluated
2018	Apple	Mac mini	Intel UHD Graphics 630	macOS Mojave (10.14.6)	Not evaluated	Not evaluated	Yes	Yes	Not evaluated	Not evaluated	Yes *9	Not evaluated

*1 Image may not display correctly after reconnecting the image cable.

*2 The laptop screen may occasionally flicker or show a black screen.

*3 Image may not display when booting with the cable connected to the monitors. Reconnecting the cables may be required.

*4 Image does not display when booting in standby mode.

*5 Having the LAN adapter connected while in Sleep Mode may cause network slowdowns due to a bug with the OS built-in network driver. (More info)

*6 The connection with USB hub may be unstable when using the Thunderbolt 3 port. It is recommended to use the USB Type-C port used to connect the AC adapter located at the far left of the laptop.

*7 We don't recommend daisy chaining the monitor via Dock 2 as operation may become unstable.

*8 Image does not display when turning off/on the power or swapping USB Type-C cable.

*9 Evaluated OS: macOS Catalina (10.15.5)

*10 "Slow charger" message on Windows can appear.

*11 Set "USB-C Display Mode" to "Extra". When this function is set to "Extra", the USB transfer speed is limited to a maximum of 480 Mbps (high speed).

*12 When monitors are connected via daisy chain, the last monitor in the chain may not recover from standby mode. Reconnecting the cables may be required.