

1. Outline

We have tested the display compatibility between Mac mini 2018 and EIZO monitors.

Note: This information is provided based on our in-house testing and we do not guarantee the compatibility in respective user environments.

[Item of validation]

- Displays BIOS image correctly
- Displays the image correctly with the recommended resolution and refresh rate
- Plug & Play works correctly
- Colors of the image are correct
- Noise and blinking do not occur
- Power save, "Sleep" and "Shut down" functions work correctly
- The calibration function of ColorNavigator works correctly. (Only ColorEdge series equipped with USB Type-C connector)

2. Applicable Monitors

ColorEdge series

3. Validation Result
MacBook Pro 2018

GPU : Intel UHD Graphics 630

OS : macOS Mojave (10.14.1 ~ 10.14.6)

Video output		Thunderbolt 3 (USB Type-C)				
Cable / Adapter type		USB Type-C	USB Type-C to DisplayPort	USB Type-C to HDMI		
Product name of cable		EIZO CC200SS	EIZO CP200	Belkin F2CU038btBLK + EIZO HH200PR	Apple MUF82ZA + EIZO HH200PR	
Monitor	Video input	Compatibility				
ColorEdge	CG319X	DisplayPort	–	Not evaluated	–	–
		HDMI	–	–	Not evaluated	Not supported *
	CG279X	USB Type-C	Yes	–	–	–
		DisplayPort	–	Not evaluated	–	–
		HDMI	–	–	Not evaluated	Not evaluated
		DVI-D	–	–	–	–
	CG2730	DisplayPort	–	Yes	–	–
		HDMI	–	–	Yes	Not evaluated
		DVI-D	–	–	–	–
	CS2740	USB Type-C	Yes	–	–	–
		DisplayPort	–	Not evaluated	–	–
		HDMI	–	–	Not evaluated	Yes
	CS2731	USB Type-C	Yes	–	–	–
		DisplayPort	–	Not evaluated	–	–
		HDMI	–	–	Not evaluated	Not evaluated
		DVI-D	–	–	–	–
	CS2730	DisplayPort	–	Yes	–	–
		HDMI	–	–	Yes	Not evaluated
		DVI-D	–	–	–	–
	CG2420	DisplayPort	–	Yes	–	–
		HDMI	–	–	Yes	Not evaluated
		DVI-D	–	–	–	–
	CS2420	DisplayPort	–	Yes	–	–
		HDMI	–	–	Yes	Not evaluated
CS2410	DisplayPort	–	Yes	–	–	
	HDMI	–	–	Yes	Not evaluated	
	DVI-D	–	–	–	–	

* Due to Adapter specification, CG319X will display at a maximum of 3840 x 2160 resolution and in limited range.